

ENVIRO H6 GENERAL ALL PURPOSE SANITISER

USE

Concentrated unperfumed multi-purpose cleaner and disinfectant.



DESCRIPTION

Highly concentrated formulation for cleaning and disinfecting all washable hard surfaces. For use in health care establishments, nursing homes, offices, schools and wherever hygiene is of the utmost importance.

FEATURES & BENEFITS

- For daily and general cleaning
- Kills bacteria and enveloped viruses
- Passes EN 1276 under dirty conditions at a dilution rate of 1:60 with a 30 second contact time
- Passes EN 16615 [adapted for commercial kitchens] under dirty conditions at a dilution rate of 1:60 with a 30 second contact time
- Low dosage, very economical in use
- Passes EN 16777 contact time and kills enveloped viruses e.g., Coronaviruses at a dilution rate of 1:60 with a 1-minute contact time.

HOW TO USE

To kill bacteria: Add 1 x 10ml from dosing cap to 600ml cold water in a trigger spray bottle (1:60). Gently shake to mix. Spray surface, leave for a 30 second contact time, then wipe with a single use cloth.

If using a bucket, add 1 x 10ml from dosing cap to 1 litre warm water (1:100). Apply to surface with a clean cloth or mop and allow to air dry.

To kill enveloped viruses e.g. Coronavirus: Clean surface before disinfection. Add 1 x 10ml from dosing cap to 600ml water in a trigger spray bottle (1:60). Gently shake to mix. Spray surface, leave for 1 minute contact time, then wipe with a single use cloth.

If using a bucket, add 2 x 10ml dose per 1L warm water in a bucket. Apply to surface with a clean cloth or mop and allow to air dry. For small areas spray onto cloth and wipe surface and allow to air dry.

TYPICAL PRODUCT DATA

Appearance: Liquid

PACKAGING

BB457-1 4 x 1 Ltr

Colour: Clear. Purple.
Odour: Unperfumed
pH – undiluted: 13.30
Shelf Life Unopened: Not less than 3 years

BIODEGRADABILITY

All surfactants used in this product comply with the current European Regulations concerning biodegradability and protection of the environment.