


## Stop Cross Contamination


Professional



**1** Apply 2 - 3 pumps into clean, dry, cupped hands.




**2** Rub hands palm to palm.




**3** Rub back of each hand with palm of other hand with fingers interlaced.




**4** Rub palm to palm with fingers interlaced.




**5** Rub with back of fingers to opposing palms with fingers interlocked.




**6** Rub each thumb clasped in opposite hand using rotational movement.



**7** Rub fingers in opposite palm in a circular motion.




**8** Rub each wrist with opposite hand.



**9** Rub until hands are dry. Steps 1 - 8 should take at least 30 seconds.



 Ensure any cuts and abrasions are covered with a clean waterproof plaster.